

SL-250500-BK

TRAILBLAZER RACING WHEEL FOR XBOX ONE

Reprogramming controls (remapping button functions)

New functions can be mapped to these 8 controls: left and right shifter paddles, gas pedal, brake pedal, R, L, forward and back gear shifter.

The following button functions can be used for mapping: 4 main buttons (Y B A X), RT, RB, LT, LB.

Programming:

1. Enter programming mode: Press and hold the 'VIEW' and 'MENU' buttons simultaneously (for around 3 seconds) until the green LED glows
2. Press the control you want to programme – the green LED will flash
3. Map the desired function to the control by pressing the relevant button (Y, B, A, X, RT, RB, LT or LB) – the LED will turn off

Additional options:

- Map the Y axis to the pedals: In programming mode, press the D-pad to the left
- Map the Y axis to the shifter paddles: In programming mode, press the D-pad to the right
- Delete individual mappings: In programming mode, press the mapped button twice
- Delete all mappings: In programming mode, press and hold 'MENU' (for around 4 seconds) until the green LED turns off

Adjusting the steering wheel sensitivity

1. Enter programming mode: Press and hold the 'VIEW' and 'MENU' buttons simultaneously (for around 3 seconds) until the green LED glows
2. Press 'VIEW'. The speed at which the green LED flashes indicates the current sensitivity level:
Low = slow flashing
Medium = medium flashing
High = rapid flashing
3. Toggle through the sensitivity levels by pressing 'VIEW'
4. Confirm the desired sensitivity level by pressing the D-pad up – the green LED will turn off