

SL-450500-BK

# TRAILBLAZER RACING WHEEL FOR PS4

## Reprogramming controls (remapping button functions)

New functions can be mapped to these 8 controls: left and right shifter paddles, gas pedal, brake pedal, L3, R3, forward and back gear shifter.

The following button functions can be used for mapping: 4 main buttons ( $\Delta$ ,  $\circ$ ,  $X$ ,  $\square$ ), L1, L2, R1, R2.

Programming:

1. Enter programming mode: Press and hold the 'SELECT/SHARE' and 'START/OPTIONS' buttons simultaneously (for around 3 seconds) until the green LED glows
2. Press the control you want to programme – the green LED will flash
3. Map the desired function to the control by pressing the relevant button ( $\Delta$ ,  $\circ$ ,  $X$ ,  $\square$ , L1, L2, R1 or R2) – the LED will turn off

Additional options:

- Map the Y axis to the pedals: In programming mode, press the D-pad to the left
- Map the Y axis to the shifter paddles: In programming mode, press the D-pad to the right
- Delete individual mappings: In programming mode, press the mapped button twice
- Delete all mappings: In programming mode, press and hold 'START/OPTIONS' (for around 4 seconds) until the green LED turns off

## Adjusting the steering wheel sensitivity

1. Enter programming mode: Press and hold the 'SELECT/SHARE' and 'START/OPTIONS' buttons simultaneously (for around 3 seconds) until the green LED glows
2. Press 'SELECT/SHARE'. The speed at which the green LED flashes indicates the current sensitivity level:  
Low = slow flashing  
Medium = medium flashing  
High = rapid flashing
3. Toggle through the sensitivity levels by pressing 'SELECT/SHARE'
4. Confirm the desired sensitivity level by pressing the D-pad up – the green LED will turn off